

Small Flat Trug

Assembly layout

All pieces need to be sanded down to remove rough edges.

Holes are pre drilled and countersunk ready for assembly using the wood screws provided.

Tools required

Sand Paper, Screwdriver.

